



1 - Main Housing	JX6/3-001	15 - Spool Spring Washer (2 req.)	JX6/3-015	31 - Drive Shaft Gear Large	JX6/3-031	47 - Pin Screw (2 req.)	JX6/3-047	61 - Crank Arm	JX6/3-061	77 - Spring Washer	JX6/3-077
2 - Gear cover	JX6/3-002	16 - Spool Spring	JX6/3-016	32 - Washer RT	JX6/3-032	48 - End House Screw (3 req.)	JX6/3-048	62 - Crank Arm Washer	JX6/3-062	78 - Lock Washer	JX6/3-078
3 - Cover Screw (2 req.)	JX6/3-003	17 - Brake Bearing	JX6/3-017	33 - Fork	JX6/3-033	49 - Drive Shaft Tube	JX6/3-049	63 - Push Knob E-Clip	JX6/3-063	79 - Nut	JX6/3-079
4 - Spool Shaft	JX6/3-004	18 - Brake Disk	JX6/3-018	34 - Fork Spring	JX6/3-034	50 - Drive Shaft Washer	JX6/3-050	64 - Crank Arm Nut	JX6/3-064	80 - Knob Cap	JX6/3-080
4A-Shaft Shoulder	JX6/3-004A	18A- Dovel Pin (4 req.)	JX6/3-018A	35 - Pusher	JX6/3-035	51 - Male Cam	JX6/3-051	65 - Push Knob	JX6/3-065	81 - Knob Cap Screws	JX6/3-081
4B-Shaft Pin	JX6/3-004B	19 - Antireverse Gear	JX6/3-019	36 - Pusher Spring	JX6/3-036	51A- Male Cam Pin (3 req.)	JX6/3-051A	66 - Lock Plate	JX6/3-066	82 - Clicker Pin	JX6/3-082
5 - Belleville Washers (6 req.)	JX6/3-005	22 - Large Pinion Gear	JX6/3-022	37 - Drive Shaft	JX6/3-037	52 - Female Cam	JX6/3-052	67 - Release Arm Spring	JX6/3-067	83 - Clicker Housing	JX6/3-083
6 - Pusher Bushing	JX6/3-006	23 - Small Pinion Gear	JX6/3-023	38 - Pusher Washer	JX6/3-038	53 - Lever Arm	JX6/3-053	68 - Spring Pin	JX6/3-068	84 - Clicker Washer	JX6/3-084
7 - Spool Bearing	JX6/3-007	24 - Pinion Bearing	JX6/3-024	39 - Pusher E-Clip	JX6/3-039	54 - Lever Knob	JX6/3-054	69 - Release Arm	JX6/3-069	85 - Clicker Spring (2 req.)	JX6/3-085
8 - Spool Tube	JX6/3-008	25 - Drive Shaft Stop Nut	JX6/3-025	40 - Drive Shaft Bearing (2 req.)	JX6/3-040	55 - Knob Screw	JX6/3-055	70 - Push Knob Cover	JX6/3-070	86 - Clicker Arm	JX6/3-086
9 - Clicker Gear Retainer Ring	JX6/3-009	25A-Stop Nut Pin	JX6/3-025A	41 - End Housing	JX6/3-041	56 - Teflon Washer (2 req.)	JX6/3-056	71 - Cover Screws (2 req.)	JX6/3-071	87 - Pin E Clip	JX6/3-087
10 - Clicker Gear	JX6/3-010	26 - Connection Arm	JX6/3-026	42 - N/A	N/A	57 - Drive Washer	JX6/3-057	72A-Handle Shaft Washer	JX6/3-071A	88 - Reel Foot	JX6/3-088
11 - Spool	JX6/3-011	27 - Friction Ring	JX6/3-027	43 - Dog	JX6/3-043	58 - Preset Washer	JX6/3-058	72 - Handle Knob Shaft	JX6/3-072	89 - Reel Foot Screw	JX6/3-089
12 - Brake Pad	JX6/3-012	28 - Washer LF	JX6/3-028	44 - Dog Cover Screw (2 req.)	JX6/3-044	59 - Preset Spring	JX6/3-059	73 - Handle Shaft Bearing	JX6/3-073	90 - Reel Foot Studs (2 req.)	JX6/3-090
13 - N/A	JX6/3-013	29 - Drive Shaft Gear Small	JX6/3-029	45 - Dog Cover	JX6/3-045	60 - Preset Knob	JX6/3-060	74 - Handle Knob	JX6/3-074	91 - Reel Foot Clamp	JX6/3-091
14 - Spool Bearing	JX6/3-014	30 - Washer MDL	JX6/3-030	46 - Stop Pin (2 req.)	JX6/3-046	60A- Preset Knob Detent (2 req.)	JX6/3-060A	75 - Knob Bearing	JX6/3-075	92 - Reel Foot Nut	JX6/3-092
								76- Knob Washer (optional)	JX6/3-076	93- MC ASSY	JX6/3-092