



For LX 6/3-MC Model ONLY

A- MC knob
B- MC Screw
C- MC Spring
D- MC Ball
E- MC Washer
F- MC housing
G- MC stator
H- MC shaft

- 93:
- A- MC knob
 - B- MC Screw
 - C- MC Spring
 - D- MC Ball
 - E- MC Washer
 - F- MC housing
 - G- MC stator
 - H- MC shaft

1 - Main Housing	LX6/3-001	15 - Spool Spring Washer (2 req.)	LX6/3-015	31 - Drive Shaft Gear Large	LX6/3-031	47 - Pin Screw (2 req.)	LX6/3-047	61 - Crank Arm	LX6/3-061	77 - Spring Washer	LX6/3-077
2 - Gear cover	LX6/3-002	16 - Spool Spring	LX6/3-016	32 - Washer RT	LX6/3-032	48 - End Housing Screw (3 req.)	LX6/3-048	62 - Crank Arm Washer	LX6/3-062	78 - Lock Washer	LX6/3-078
3 - Cover Screw (2 req.)	LX6/3-003	17 - Brake Bearing	LX6/3-017	33 - Fork	LX6/3-033	49 - Drive Shaft Tube	LX6/3-049	63 - Push Knob E-Clip	LX6/3-063	79 - Nut	LX6/3-079
4 - Spool Shaft	LX6/3-004	18 - Brake Disk	LX6/3-018	34 - Fork Spring	LX6/3-034	50 - Drive Shaft Washer	LX6/3-050	64 - Crank Arm Nut	LX6/3-064	80 - Knob Cap	LX6/3-080
4A-Shaft Shoulder	LX6/3-004A	18A- Dovel Pin (4 req.)	LX6/3-018A	35 - Pusher	LX6/3-035	51- Male Cam	LX6/3-051	65- Posh Knob	LX6/3-065	81- Knob Cap Screws	LX6/3-081
4B-Shaft Pin	LX6/3-004B	19 - Antireverse Gear	LX6/3-019	36 - Pusher Spring	LX6/3-036	51A-Male Cam Pin (3 req.)	LX6/3-051A	66- Lock Plate	LX6/3-066	82- Clicker Pin	LX6/3-082
5 - Belleville Washers (6 req.)	LX6/3-005	22 - Large Pinion Gear	LX6/3-022	37 - Drive Shaft	LX6/3-037	52- Female Cam	LX6/3-052	67- Release Arm Spring	LX6/3-067	83- Pin Support	LX6/3-083
6 - Pusher Bushing	LX6/3-006	23 - Small Pinion Gear	LX6/3-023	38 - Pusher Washer	LX6/3-038	53-Lever Arm	LX6/3-053	68- Spring Pin	LX6/3-068	84- Pin Washer	LX6/3-084
7 - Spool Bearing	LX6/3-007	24 - Pinion Bearing	LX6/3-024	39 - Pusher E-Clip	LX6/3-039	54- Lever Knob	LX6/3-054	69- Release Arm	LX6/3-069	85- Clicker Spring (2 req.)	LX6/3-085
8 - Spool Tube	LX6/3-008	25 - Drive Shaft Stop Nut	LX6/3-025	40 - Drive Shaft Bearing (2 req.)	LX6/3-040	55- Knob Screw	LX6/3-055	70- Push Knob Cover	LX6/3-070	86- Clicker Arm	LX6/3-086
9 - Clicker Gear Retainer Ring	LX6/3-009	25A-Stop Nut Pin	LX6/3-025A	41 - N/A	LX6/3-041	56-Teflon Washer (2 req.)	LX6/3-056	71 - Cover Screws (2 req.)	LX6/3-071	87- Pin E Clip	LX6/3-087
10- Clicker Gear	LX6/3-010	26 - Connection Arm	LX6/3-026	41 - N/A	LX6/3-041A	57- Drive Washer	LX6/3-057	72A-Handle Shaft Washer	LX6/3-071A	88- Reel Foot	LX6/3-088
11- Spool	LX6/3-011	27 - Friction Ring	LX6/3-027	43 - Dog	LX6/3-043	58- Preset Washer	LX6/3-058	72- Handle Knob Shaft	LX6/3-072	89- Reel Foot Screw	LX6/3-089
12- Brake Pad	LX6/3-012	28 - Washer LF	LX6/3-028	44 - Dog Cover Screw (2 req.)	LX6/3-044	59- Preset Spring	LX6/3-059	73- Handle Shaft Bearing	LX6/3-073	90- Reel Foot Studs (2 req.)	LX6/3-090
13- N/A	LX6/3-013	29 - Drive Shaft Gear Small	LX6/3-029	45 - Dog Cover	LX6/3-045	60- Preset Knob	LX6/3-060	74- Handle Knob	LX6/3-074	91- Reel Foot Clamp	LX6/3-091
14- Spool Bearing	LX6/3-014	30 - Washer MDL	LX6/3-030	46 - Stop Pin (2 req.)	LX6/3-046	60a- Preset knob Detent (2 req.)	LX6/3-060a	75- Knob Bearing	LX6/3-075	92- Reel Foot	LX6/3-092
								76- Knob Washer (optional)	LX6/3-076	93- MC ASSY	LX6/3-093