


AVETREELS

MXJ6/4 RAPTOR - MXL6/4 RAPTOR



AVETREELS

MXJ6/4 RAPTOR - MXL6/4 RAPTOR

01. CLICKER BUTTON
 - 02-a. CLICKER HOUSING (OLD STYLE)
 - 02-b. CLICKER HOUSING (NEW STYLRL)
03. FRAME
04. CLICKER SET (OLD STYLE)
 - 04-a. CLICKER WASHER
 - 04-b. CLICKER DOG
 - 04-c. E-CLIP
 - 04-d. CLICKER DOG
 - 04-e. CLICKER SET (NEW STYLE)
05. GEAR COVER
06. GEAR COVER SCREW (PACK OF 2)
07. SPOOL SHAFT
09. BELLEVILLE WASHERS (PACK OF 6)
09. THRUST BUSHING
10. SPOOL BEARING
11. CLICKER GEAR RETAINER RING
12. CLICKER GEAR
13. SPOOL
14. SPOOL SHAFT TUBE
15. SPOOL BEARING
16. THRUST WASHER
17. INNER BRAKE DISC BEARING
18. INNER BRAKE DISC
19. BRAKE PAD
20. DRAG SPRING
21. OUTER BRAKE DISC BEARING
22. OUTER BRAKE DISC
23. LARGE PINION GEAR
24. SMALL PINION GEAR
25. PRESET KNOB
26. PRESET KNOB SPRING
27. PRESET KNOB SPRING WASHER
28. PIVOT PLATE
29. PIVOT PLATE WASHER (PACK OF 2)
30. LEVER 30
31. FEMALE CAM
 - 31-a. MALE CAM
32. BUMPER SCREW (PACK OF 2)
33. LEVER STOP BUMPER (PACK OF 2)
34. GLIDE PLATE
35. GLIDE PLATE SPACER (PACK OF 2)
36. PUSH KNOB COVER SCREW (PACK OF 2)
37. PUSH KNOB COVER
38. RELEASE ARM
39. RELEASE ARM SPRING
40. PUSH KNOB LOCK PLATE
41. PUSH KNOB
42. PUSH KNOB WASHER
43. RELEASE ARM PIN
44. HANDLE KNOB
 - 44-a. HANDEL KNOB INSIDE SET
45. HANDLE ARM
46. HANDLE ARM THRUST WASHER
47. DRIVE SHAFT BEARING
48. ENDOUSING TUBE
49. ENDOUSING SCREW (PACK OF 3)
50. ENDOUSING
51. PINION BEARING
52. DRIVE SHAFT BEARING
53. DRIVE SHAFT
54. DRIVE SHAFT LARGE GEAR
55. DRIVE SHAFT LARGE GEAR SPACER
56. DRIVE SHAFT SMALL GEAR
57. ANTI REVERSE FRICTION RIGN KNOB
58. DRIVE SHAFT STOP NUT
59. FRICTION RING
60. ANTI REVERSE CONNECTING ARM
61. DOG
62. DOG COVER
63. DOG COVER SCREW (PACK OF 2)
64. REEL FOOT
65. REEL FOOT INNER SCREW (PACK OF 2)
66. REEL FOOT OUTER SCREW (PACK OF 4)
67. CLAMP SET
 - 67-a. CLAMP
 - 67-b. CLAMP SCREW (PACK OF 2)
68. MC SET
 - 68-a. MC KNOB
 - 68-b. MC SET SCREW
 - 68-c. MC BALL
 - 68-d. MC SPRING
 - 68-e. MC WASHER
 - 68-f. MC HOUSING
 - 68-g. MC SHAFT