



- 01. CLICKER BUTTON
- 02. CLICKER HOUSING
- 04. FRAME
- 05. CLICKER SET
- 05-a. CLICKER WASHER
- 05-b. CLICKER DOG
- 05-c. E-CLIP
- 06. GEAR COVER
- 07. GEAR COVER SCREW ( PACK OF 2 )
- 08. SPOOL SHAFT
- 09. BELLEVILLE WASHERS ( PACK OF 4 )
- 10. THRUST BUSHING
- 11. SPOOL BEARING
- 12. CLICKER GEAR RETAINER RING
- 13. CLICKER GEAR
- 14. SPOOL
- 15. SPOOL SHAFT TUBE
- 16. SPOOL BEARING
- 17. THRUST WASHER
- 18. DRAG SPRING
- 19. THRUST WASHER
- 20. DRAG BEARING
- 21. BRAKE DISC
- 22. LARGE PINION GEAR
- 23. SMALL PINION GEAR
- 24. PRESET KNOB
- 25. PRESET KNOB SPRING
- 26. PRESET KNOB SPRING WASHER
- 27. PIVOT PLATE
- 28. PIVOT PLATE WASHER ( PACK OF 2 )
- 29. LEVER
- 30. FEMALE CAM
- 30-a. MALE CAM
- 31. BUMPER SCREW ( PACK OF 2 )
- 32. LEVER STOP BUMPER ( PACK OF 2 )
- 32-a. GLIDE PLATE
- 32-b. GLIDE PLATE SPACER ( PACK OF 2 )
- 33. PUSH KNOB COVER SCREW ( PACK OF 2 )
- 34. PUSH KNOB COVER
- 35. RELEASE ARM
- 36. RELEASE ARM SPRING
- 37. PUSH KNOB LOCK PLATE
- 38. PUSH KNOB
- 39. PUSH KNOB WASHER
- 40. RELEASE ARM PIN
- 41. HANDLE KNOB
- 41-a. HANDLE KNOB INSIDE SET
- 42. HANDLE ARM
- 43. HANDLE ARM THRUST WASHER
- 44. DRIVE SHAFT BEARING
- 45. ENDOUSING TUBE
- 46. ENDOUSING SCREW ( PACK OF 3 )
- 47. ENDOUSING
- 48. PINION BEARING
- 49. DRIVE SHAFT BEARING
- 50. DRIVE SHAFT
- 51. DRIVE SHAFT LARGE GEAR
- 52. DRIVE SHAFT LARGE GEAR SPACER
- 53. DRIVE SHAFT SMALL GEAR
- 54. ANTI REVERSE FRICTION RING KNOB
- 55. DRIVE SHAFT STOP NUT
- 56. FRICTION RING
- 57. ANTI REVERSE CONNECTING ARM
- 58. DOG
- 59. DOG COVER
- 60. DOG COVER SCREW ( PACK OF 2 )
- 61. REEL FOOT
- 62. REEL FOOT INNER SCREW( PACK OF 2 )
- 63. REEL FOOT OUTER SCREW ( PACK OF 4 )
- 64. CLAMP SET
- 64-a. CLAMP
- 64-b. CLAMP SCREW ( PACK OF 2 )
- 65. MC SET
- 65-a. MC KNOB
- 65-b. MC SET SCREW
- 65-c. MC BALL
- 65-d. MC SPRING
- 65-e. MC WASHER
- 65-f. MC HOUSING
- 65-g. MC SHAFT